

Installation Guide

Mounting your Rotary Clamp or Backstop on the scissor lift side of the rotary.

Use your fancy laser to cut this bad boy out to use as a template for marking your holes. I would recommend using a punch, nail or screw to gently mark where you will drill your holes. A #21 bit is recommended, but a 5/32 will work too. Once the holes are drilled, use a 10-32 tap to thread the proper holes for the thumb screws.

Don't have a tap? Harbor Freight has a set for about \$15 that includes the 10-32 tap. A good hardware store or Fastenal will also be able to get you set up.

